



Specifications for applying the  
**SkateMaster Coating System**  
For In-Line Hockey

CMT - 34

Revised: 6/03

**PRODUCT NAME:**

SkateMaster Coating  
System For In-Line Hockey

**MANUFACTURER:**

SealMaster  
2520 S. Campbell St.  
Sandusky, OH 44870  
Phone: 800-395-7325  
Fax: 419-626-5477  
www.sealmaster.net

*Additional Plant Locations:*  
SealMaster has a nationwide  
network of manufacturing and  
distribution facilities.

Phone us at 1-800-395-7325  
or visit our website at  
www.sealmaster.net to find the  
location near you.

**1. SCOPE:**

1.1  
The following specifications pertain  
to the application of the  
SkateMaster Coating System for In-  
Line Hockey.

**2. SURFACE PREPARATION:**

2.1  
New asphalt surfaces must cure 30  
days prior to application. The  
surface must be cleaned entirely  
of dust, dirt, debris, and all loose  
materials.

2.2  
Fill all cracks with Acrylic Crack  
Patch, or other suitable crack filler.

2.3

Level depressions or "bird baths" (?  
inch or deeper) with SportMaster  
Acrylic Patch Binder or Acrylic  
Resurfacer patching mix.

2.4

Apply one coat of SportMaster  
Acrylic Resurfacer in accordance  
with manufacturer's mixing and  
application instructions.

*Important* - The sand used in the  
Acrylic Resurfacer should be a 70  
mesh or finer. Extremely porous  
asphalt may require a second coat  
of resurfacer.

**3. APPLICATION OF  
SKATEMASTER:**

3.1

Over properly prepared asphalt  
surface, apply two coats of  
SkateMaster coating in  
accordance with manufacturer's  
instructions.

**4. LINE MARKINGS:**

4.1

All line markings shall be laid out in  
accordance with The National In-  
Line Hockey Association guidelines.

4.2

Apply one or two coats of  
SportMaster Line Paint.